

1 Kit Contents / Packing List

- Assembled and tested evaluation board/module in anti-static bag.
- Warranty card

2 Jump Start

- Go to www.freescale.com/analogtools
- Locate your kit
- Review your Tool Summary Page
- Look for



Jump Start Your Design

- Download documents, software and other information

3 Important Notice

Freescale provides the enclosed product(s) under the following conditions:

This evaluation kit is intended for use of ENGINEERING DEVELOPMENT OR EVALUATION PURPOSES ONLY. It is provided as a sample IC pre-soldered to a printed circuit board to make it easier to access inputs, outputs, and supply terminals. This EVB may be used with any development system or other source of I/O signals by simply connecting it to the host MCU or computer board via off-the-shelf cables. This EVB is not a Reference Design and is not intended to represent a final design recommendation for any particular application. Final device in an application will be heavily dependent on proper printed circuit board layout and heat sinking design as well as attention to supply filtering, transient suppression, and I/O signal quality.

The goods provided may not be complete in terms of required design, marketing, and or manufacturing related protective considerations, including product safety measures typically found in the end product incorporating the goods. Due to the open construction of the product, it is the user's responsibility to take any and all appropriate precautions with regard to electrostatic discharge. In order to minimize risks associated with the customers applications, adequate design and operating safeguards must be provided by the customer to minimize inherent or procedural hazards. For any safety concerns, contact Freescale sales and technical support services.

Should this evaluation kit not meet the specifications indicated in the kit, it may be returned within 30 days from the date of delivery and will be replaced by a new kit.

Freescale reserves the right to make changes without further notice to any products herein. Freescale makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typical", must be validated for each customer application by customer's technical experts.

Freescale does not convey any license under its patent rights nor the rights of others. Freescale products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale product could create a situation where personal injury or death may occur.

Should the buyer purchase or use Freescale products for any such unintended or unauthorized application, the buyer shall indemnify and hold Freescale and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale was negligent regarding the design or manufacture of the part. Freescale™ and the Freescale logo are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners.

© Freescale Semiconductor, Inc. 2014.

8 Evaluation Board Configuration




Figure 2. Evaluation Board Setup

9 Installing SPIGen Freeware on your Computer

The latest version of SPIGen is designed to run on any Windows 8, Windows 7, Vista or XP-based operating system. To install the software, go to www.freescale.com/analogtools and select your kit. Click on that link to open the corresponding Tool Summary Page. Look for “Jump Start Your Design”. Download to your computer desktop the SPIGen software as well as the associated configuration file.

Run the install program from the desktop. The Installation Wizard will guide you through the rest of the process.

To use SPIGen, go to the Windows Start menu, then Programs, then SPIGen, and click on the SPIGen icon. The SPIGen Graphic User Interface (GUI) will appear. Go to the file menu in the upper left hand corner of the GUI, and select “Open”. In the file selection window that appears, set the “Files of type:” drop-down menu to “SPIGen Files (*.spi)”. (As an exceptional case, the file name may have a .txt extension, in which

Installing SPIGen Freeware on your Computer

case you should set the menu to “All Files (*.*)”. Next, browse for the configuration file you saved on your desktop earlier and select it. Click “Open”, and SPIGen will create a specially configured SPI command generator for your evaluation board.

The GUI is shown in [Figure 3](#). The text at the top is the name of the configuration file loaded. The left side panel displays folders that group user interfaces. The interfaces in the pre-installed MC33816 folder pertain specifically to the board under discussion. The process of loading the configuration file has assigned a list of “Extra Pins” as well as a list “Quick Commands”, all of which are board-specific.




Figure 3. SPI Generator GUI

10 Setup and Using the Hardware

To perform the examples included in the software bundle, the following connections and setup must be performed:

1. Make sure the SPIGen 7.0 or higher program is installed on the PC and it can communicate with the USB/SPI dongle, as described in that kit's documentation.
2. Connect the USB/SPI dongle to the MC33816 EVB via a 16 conductor ribbon cable. Make sure to orient the cable connectors so that pin1 on both the USB/SPI dongle and the MC33816 EVB are connected correctly, pin 1 to pin 1.
3. Connect the USB/SPI dongle to a PC. LED 2 on the USB/SPI dongle and the USB_PWR LED on the MC33816 EVB should both be illuminated. Reprogram the USB/SPI dongle with the MC33816 USB/SPI dongle image. The image is version 2.3.1, and is available in the Downloads section of the KIT33816AEEVM web page. See the SPIGen User's Guide for instructions on how to reprogram the USB/SPI dongle.
4. Attach the +12 VDC supply (do not turn on power yet) to the VSUPP input connector on the MC33816 EVB, making sure to observe the GND and +12 V terminals. The current capability of the +12 V supply should exceed the maximum total current that the number of simultaneously ON loads will require.
5. Attach loads (Injectors) to the INJ1, INJ2, INJ3, and INJ4 output terminals (and optionally FP1 and FP2), as desired
6. Turn on the +12 volt supply. Verify that all is working correctly by observing the +3.3 V and +5.0 V LEDs, which should be illuminated.

10.1 Running an example program

1. Launch the SPIGen program.
2. Load the config file, by clicking on "File" then "Open" and browsing to the KIT33816AESW.spi file located inside the "Injector Demo Files" directory.
3. Go to the "Single Command" page in SPIGen and set the RESETB pin high.
4. Go to the "Micro code" page under "MC33816" and click on the folder icon on the right side of the "Code Ram 1" edit box. Browse to the location of the MC33816_ch1.cip.bin file, select it, and click on the "Open" button.
5. Click on the folder icon on the right side of the "Code Ram 2" edit box. Browse to the location of the MC33816_ch2.cip.bin file, select it, and click on the "Open" button.
6. Continue by selecting the Data Ram and Register files located inside the same directory as the microcode files. The file names should be self explanatory. After selecting all the files click "Download All" and wait for a confirmation message. Click on the "Save Filenames" button to save the code and register file configuration.
7. Click the "Enable Flash on CH1 and Ch2" button to run the code. At this point both channels should be operational.
8. Go to the "Single command" page and set the DRVEN pin high. This will enable all of the pre-drivers and the DC-DC boost converter should also start regulating. Approximately 40 V should be measured on the VBOOST output pin.

10.2 Running the example batch files

1. Go to the "Batch commands" page and select the batch file you want to run. There are 5 choices. "Start1" through "Start4" pulse only one injector (1, 2, 3, or 4). The "Start1-4" batch command pulses all four injectors in sequence.
2. Click on the "Send Continuously" button and observe that the four loads attached to the MC33816 EVB board are turning on and then off in succession.

There are other demo batch examples that can be run and examined for learning how to use the EVB.

11.1 LED Display

Five LED's are provided as visual output devices for the MC33816 EVB. A list of the LED devices is shown by the following:

1. **+3.3 V LED** - Indicates that the +3.3 volt regulator is running.
2. **FLAG0 LED** - Indicates that the digital FLAG 0 output is a logic 1.
3. **FLAG1 LED** - Indicates that the digital FLAG 1 output is a logic 1.
4. **FLAG2 LED** - Indicates that the digital FLAG 2 output is a logic 1.
5. **+5.0 V LED** - Indicates that the +5.0 volt regulator is running.
6. **USB_PWR LED** - Indicates that the USB SPI dongle is connected properly and is attached to an active USB port on a PC.

11.2 Test Point Definitions

The EVB contains forty-six (46) test points that provide access to certain signals in the MC33816 as follows:

1. **+3.3 V** - +3.3 Volt regulator output
2. **+5.0 V** - +5.0 Volt regulator output
3. **VCCP** - VCCP device pin
4. **VCCIO** - VCCIO device pin
5. **VBAT** - VBAT device pin
6. **PGND** - power ground
7. **VBOOST** - DC-DC convertor output, 0 to 72 V
8. **DGND** - digital ground
9. **CLK** - CLK device pin for external clocking
10. **RESETB** - RESETB device pin for reset
11. **DRVEN** - DRVEN device pin for enabling the pre-drivers
12. **IRQB** - IRQB device pin, output for MCU hardware interrupt
13. **MISO** - MISO device pin for SPI for data out
14. **MOSI** - MOSI device pin for SPI for data in
15. **SCLK** - SCLK device pin for SPI clock
16. **CSB** - CSB device pin for SPI chip select
17. **START1** - START1 device pin for injector 1 (INJ1) output control
18. **START2** - START2 device pin for injector 2 (INJ2) output control
19. **START3** - START3 device pin for injector 3 (INJ3) output control
20. **START4** - START4 device pin for injector 4 (INJ4) output control

21. **START5** - START5 device pin for fuel pump 1 (FP1) output control
22. **START6** - START6 device pin for fuel pump 2 (FP2) output control
23. **VSENSEP4** - VSENSEP4 device pin, voltage across R12 current sense resistor for the DC-DC converter
24. **VSENSEN4** - VSENSEN4 device pin, voltage across R12 current sense resistor for the DC-DC converter
25. **PGND** - power ground
26. **G_HS1** - G_HS1 device pin for HS1 driver control
27. **G_HS3** - G_HS3 device pin for HS3 driver control
28. **G_HS5** - G_HS5 device pin for HS5 driver control
29. **G_HS2** - G_HS2 device pin for HS2 driver control
30. **G_HS4** - G_HS4 device pin for HS4 driver control
31. **G_LS5** - G_LS5 device pin for LS5 driver control
32. **G_LS1** - G_LS1 device pin for LS1 driver control
33. **G_LS3** - G_LS3 device pin for LS3 driver control
34. **G_LS6** - G_LS6 device pin for LS6 driver control
35. **G_LS2** - G_LS2 device pin for LS2 driver control
36. **G_LS4** - G_LS4 device pin for LS4 driver control
37. **VSENSEP3** - VSENSEP3 device pin, voltage across R26 current sense resistor for the fuel pump bank
38. **VSENSEP1** - VSENSEP1 device pin, voltage across R21 current sense resistor for the injector bank 1
39. **VSENSEP2** - VSENSEP2 device pin, voltage across R22 current sense resistor for the injector bank 2
40. **VSENSEN3** - VSENSEN3 device pin, voltage across R26 current sense resistor for the fuel pump bank
41. **VSENSEN1** - VSENSEN1 device pin, voltage across R21 current sense resistor for the injector bank 1
42. **VSENSEN2** - VSENSEN2 device pin, voltage across R22 current sense resistor for the injector bank 2
43. **PGND** - power ground
44. **PGND** - power ground
45. **PGND** - power ground
46. **G_LS7** - G_LS7 device pin for LS7 driver control

11.3 Input Signal Definitions

The MC33816 EVB has nine logic level input signals used to control certain outputs or functions inside the circuit. These 9 signals are:

1. **DRVEN** - Controls the state of the all the pre-driver outputs
2. **RESETB** - When the RESETB line is held low, the MC33816 is reset
3. **START1** - Provides start signal for Injector 1
4. **START2** - Provides start signal for Injector 2

11.7 MC33816 EVB Connectors




Figure 5. KIT33816AEEVM Evaluation Board Diagram

11.7.1 Input Connector

There is one input connector used to connect the EVB to +12 V.

1. (VSUPP) +12 VOLT POWER SUPPLY INPUT -
 - Screw Terminal 1 (+) +12 V
 - Screw Terminal 2 (-) GND

11.7.2 Output Connectors

There are six output connectors that provide the four injector and two fuel pump output signals:

- 1) (INJ1) INJECTOR OUTPUT 1 -
Screw Terminal 1 - High-side drive
Screw Terminal 2 - Low-side drive
2. (INJ2) INJECTOR OUTPUT 2 -
Screw Terminal 1 - High-side drive
Screw Terminal 2 - Low-side drive
3. (INJ3) INJECTOR OUTPUT 3 -
Screw Terminal 1 - High-side drive
Screw Terminal 2 - Low-side drive
4. (INJ4) INJECTOR OUTPUT 4 -
Screw Terminal 1 - High-side drive
Screw Terminal 2 - Low-side drive
5. (FP1) FUEL PUMP OUTPUT 1 -
Screw Terminal 1 - Low-side drive
Screw Terminal 2 - High-side drive
6. (FP2) FUEL PUMP OUTPUT 2 -
Screw Terminal 1 - Low-side drive
Screw Terminal 2 - High-side drive

11.8 Accessory Boards

The KITUSBSPIDGLEVME Evaluation board (shown below) provides a USB to SPI interface that features the MC68HC908JW32 with dongle. It is a working hardware/software example that allows a user to become familiar with the MC68HC908JW32 microcontroller by means of an actual useful application, a USB to SPI and USB to parallel converter. The main function provided by this kit is to allow a PC, that may not have a parallel port, to communicate with other Freescale Evaluation Kits, via a USB port. The USB port is a standard feature on almost every new PC. This kit makes use of the MC68HC908JW32's built-in USB, SPI and parallel ports.



Figure 6. KITUSBSPIDGLEVME Evaluation Kit

Quantity	Schematic Label	Value	Description and Values	Manufacturer Name	Part Number	PCB Footprint
4	J2, J5-J7	HDR_1X 3	HDR 1X3 TH 100MIL SP 319H AU 130L	3M	961103-6404-AR	Header 1X3
2	J3, J4	SHRD 2X8	CON 2X8 SHRD TH 100MIL CTR 366H AU 118L	Sullins Electron- ics Corp	SBH11-PBPC-D08- ST-BK	CON- NECTOR 2X8
6	J8-J13	OSTTG0 25100B	CON 1X2 TB TH 5.08MM 504H -- 177L	ON-Shore Tech- nology	OSTTG025100B	Connec- tor 1X2

Inductors

1	L1	6.0 µH	IND ROD CHK 6µH@10KHZ 10A 25% TH	Würth Elektronik Eisos Gmbh & Co. Kg	744710610	
1	L2	10 µH	IND PWR 10UH@100KHZ 16A 20% SMT	Bourns	SRP1250-100M	SMT

Transistors

1	Q1	AOD4185	TRAN PMOS PWR 40A 40V TO252	Alpha and Omega Semicon- ductor	AOD4185	TO252AA
12	Q2-Q13	BUK9230 -100B	TRAN NMOS PWR SW 47A 100V DPAK	NXP Semicon- ductors	BUK9230-100B,118	DPAK

Resistors

1	R1	100 K	RES MF 100K 1/10W 5% 0'0603	Bourns	CR0'0603-JW-104E LF	0603
5	R2, R4-R7	470	RES MF 470 OHM 1/10W 5% 0'0603	Venkel Company	CR0'0603-10W-471 JT	0603
1	R3	180	RES MF 180 OHM 1/10W 5% 0'0603	KOA Speer	RK73B1JTTD181J	0603
1	R8	2.2	RES MF 2.2 OHM 1/10W 5% 0'0603	Panasonic	ERJ3GEYJ2R2V	0603
2	R9, R10	5.1	RES MF 5.1 OHM 1/10W 5% 0'0603	KOA Speer	RK73B1JTTD5R1J	0603
12	R11, R13-R20, R23-R25	10	RES MF 10 OHM 1/10W 5% AEC-Q200 0'0603	Vishay Intertech- nology	CRCW0'060310R0J NEA	0603
1	R12	0.010	RES METAL STRIP 0.01 OHM 1W 1% 2512	Vishay Intertech- nology	WSK2512R0100FE A	2512_4P
3	R21, R22, R26	0.015	RES MF 0.015 OHM 1W 1% AEC-Q200 2512	Vishay Intertech- nology	WSK2512R0150FE A	2512_4P

Test points

46	TP1-TP45	3.65x2.05 MM	TEST POINT 3.65x2.05MM SMT	Harwin INC	S1751-46R	
----	----------	-----------------	----------------------------	------------	-----------	--

Integrated Circuits

1	U1	MC78L05 ACHX	IC VREG 5V 100MA 30V SOT-89	Fairchild	MC78L05ACHX	SOT89
1	U2	TC1055- 3.3 VCT7 13	IC VREG LDO 3.3V 100MA 2.7-6V SOT23-5	Microchip Tech- nology INC	TC1055-3.3VCT713	SOT23-5

15 References

The following table contains URLs where you can obtain information on KIT33816AEEVM and other Freescale products and product solutions:

Freescale.com Support Pages	URL
MC33816 Product Summary Page	http://www.freescale.com/webapp/sps/site/prod_summary.jsp?code=MC33816
KITUSBSPIDGLEVME Tool Summary Page	http://www.freescale.com/webapp/sps/site/prod_summary.jsp?code=KITUSBSPIDGLEVME
SPIGen Reference Tool Summary Page	http://www.freescale.com/files/soft_dev_tools/software/device_drivers/SPIGen.html?fsrch=1&sr=11
Analog Home Page	www.freescale.com/analog
Automotive Home Page	www.freescale.com/automotive

15.1 Support

Visit Freescale.com/support for a list of phone numbers within your region.

15.2 Warranty

Visit Freescale.com/warranty for a list of phone numbers within your region.

16 Revision History

Revision	Date	Description of Changes
1.0	2/2013	• Initial Release
2.0	4/2013	• Add Jump Start link for downloading software and/or documents. • Update SPIGen section to match latest template
3.0	1/2014	• Added new KIT33816AEEVM evaluation board. • Update all information to match the new board configuration.

How to Reach Us:

Home Page:
freescale.com

Web Support:
freescale.com/support

Information in this document is provided solely to enable system and software implementers to use Freescale products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits based on the information in this document.

Freescale reserves the right to make changes without further notice to any products herein. Freescale makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale data sheets and/or specifications can and do vary in different applications, and actual performance may vary over time. All operating parameters, including "typicals," must be validated for each customer application by customer's technical experts. Freescale does not convey any license under its patent rights nor the rights of others. Freescale sells products pursuant to standard terms and conditions of sale, which can be found at the following address: freescale.com/SalesTermsandConditions.

Freescale and the Freescale logo are trademarks of Freescale Semiconductor, Inc., Reg. U.S. Pat. & Tm. Off.SMARTMOS is a trademark of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners.

© 2014 Freescale Semiconductor, Inc.

Document Number: KT33816UG
Rev. 3.0
1/2014