

| APPLICATOR PARTS LIST | | | | TYPE .250 SERIES LENGTHWISE FASTON RECEPT. | | | AMP INCORPORATED HARRISBURG, PENNA. | | | | | |
|-----------------------|----------------------------------|------|-------------------|--|--------------------|------|-------------------------------------|--|--------------|------|-----------|--|
| NO. | DESCRIPTION | REQ. | PART NO. | NO. | DESCRIPTION | REQ. | PART NO. | CRIMPING DATA | | | TERMINALS | |
| 1 | WIRE CRIMPER 1-45-917-3 | 1 | 548937 | 42 | | | | TO APPLY TERMINAL | | | L1771 | |
| 2 | INS. CRIMPER | 1 | 378247 | 43 | | | | | | | L1772 | |
| 3 | ANVIL | 1 | 810348 | 44 | Hold Down | 1 | 375896 | WIRE SIZE | CRIMP HEIGHT | | 42286 | |
| 4 | ANVIL SPACER | | | 45 | Cleaner Spacer | 1 | 385530 | 22 | .045 | | 42510 | |
| 5 | SHEAR BLADE | 1 | 385301 | 46 | Crimper Cleaner | 1 | 375089 | | | | 42602 | |
| 6 | REAR SHEAR PLATE 385013-4 | 1 | 371638 | 47 | | | | 20 | .048 | | 60316 | |
| 7 | SHEAR BLADE SPACER | 2 | 370709 | 48 | Hold Down Assy. | 1 | 811849-1 | | | | 60352 | |
| 8 | FRONT SHEAR PLATE | 1 | 810347-7 | 49 | | | | 18 | .052 | | | |
| 9 | REAR ANVIL SPACER PLT. | | | 50 | | | | CRIMP | SIZE | TYPE | FEED | |
| 10 | FRONT ANVIL SPACER PLT. | | | 51 | | | | WIRE | .090 | "F" | | |
| 11 | TOOL SPACER | 1 | 370275 | 52 | | | | INSUL. | .130 | "F" | .845 | |
| 12 | CRIMP SPACER | 1 | 370873 | 53 | | | | SLEEVED | | | | |
| 13 | FRONT STRIP GUIDE | 1 | 371633 | 54 | | | | INSULATION RANGE | WIRE RANGE | | | |
| 14 | REAR STRIP GUIDE | 1 | 371638 | 55 | | | | .090 - .130 | 22 - 18 | | | |
| 15 | RAM | 1 | 471911 | 56 | | | | EXPLODED VIEW | | | | |
| 16 | TOOL HOLDER | | | 57 | | | | A-6000 A-6000-4 | | | | |
| 17 | ADJ. CRIMP MOUNT ASSY. | 1 | 465392-1 | 58 | | | | REMARKS: | | | | |
| 18 | ADJ. BLOCK | | | 59 | | | | | | | | |
| 19 | APPLICATOR MOUNT XXXX | 1 | 570656 | 60 | | | | | | | | |
| 20 | BASE PLATE | | | 61 | | | | | | | | |
| 21 | BASE BLOCK | | | 62 | | | | | | | | |
| 22 | STRIP GUIDE PLATE | | | 63 | | | | | | | | |
| 23 | ANVIL HOLDER | 1 | 370526 | 64 | | | | | | | | |
| 24 | AUX. ANVIL HOLDER | 1 | 377515 | 65 | TENSION ADJ. PLATE | 1 | 374999 | | | | | |
| 25 | STRIPPER | 1 | 465743-1 | 66 | MISCELLANEOUS | | | <div style="border: 1px solid black; padding: 2px;"> THIS DRAWING IS A CONTROLLED DOCUMENT FOR AMP INC. IT IS SUBJECT TO CHANGE AND THE CONTROLLING ENGINEERING ORGANIZATION SHOULD BE CONTACTED FOR THE LATEST REVISION. </div> | | | | |
| 26 | STRIPPER MOUNT | 1 | 370660 | 67 | | | | | | | | |
| 27 | RETAINER PLATE | 1 | 372251 | 68 | | | | | | | | |
| 28 | STRIPPER MOUNT BRACKET | | | 69 | | | | | | | | |
| 29 | STRIPPER BUSHING | | | 70 | MICH. FEED ASSY. | 1 | 69240-2 | | | | | |
| 30 | STOCK DRAG | 1 | 375381 | 71 | | | | | | | | |
| 31 | STOCK DRAG HANDLE | 1 | 375381 | 72 | | | | | | | | |
| 32 | STOCK DRAG STUD | 2 | 354045-1 | REV. | REVISION RECORD | DATE | BY | ECN | | | | |
| 33 | STOCK DRAG SPRING 1-23847-1 | 2 | 370709 | G | 0150-6426-95 | 9/95 | 685/26 | | | | | |
| 34 | STOCK DRAG ADJ. SCREW | 2 | 372997 | | | | | | | | | |
| 35 | FEED FINGER HOLDER | | | | | | | | | | | |
| 36 | FEED FINGER | 1 | 375093 | | | | | | | | | |
| 37 | FEED FINGER TIP | | | | | | | | | | | |
| 38 | FEED FINGER SPACER | | | | | | | | | | | |
| 39 | BASE CASTING | 1 | 570238 | | | | | | | | | |
| 40 | GUARD | 1 | 45766A-1 | | | | | | | | | |
| 41 | | | | | | | | | | | | |

THIS DRAWING IS A CONTROLLED DOCUMENT FOR AMP INC. IT IS SUBJECT TO CHANGE AND THE CONTROLLING ENGINEERING ORGANIZATION SHOULD BE CONTACTED FOR THE LATEST REVISION.

RECOMMENDED SPARE PARTS

THIS APPLICATOR IS TO BE USED ON AMP-O-LECTRIC

Alignment Gage 679597-1

SERIAL NO. DATE SHIPPED

CUSTOMER NAME AND ADDRESS

APPLICATOR NUMBER REV. 672466-3

DIST. 4

DESIGNED

CHK'D. 4-0-65

APP'D. 4-0-65

SHEET 1 OF 1